



HIGHTACK ADHESIVE RECOMMENDATIONS

Aside from cleaning media clamps and all prior to use,
And before loading the material:

Place a 2inch wide strip of painter's tape on both sides of the pre and post heat area of the printer. Don't cover the grit rollers. Make sure the edges of the material is on the blue tape so its aligned on both sides in the center of the tape.

Make sure the left and right pinch rollers are not on the edge of the material as it will push adhesive across the edges.

The tape will prevent the adhesive from transferring to the heating element.

And of course, make sure someone is there to supervise it every 20 mins.

The small "shrink" where we see the liner edge is common and not a default for the material.